


PRO-DPC INSTALLATION & SETUP GUIDE WITH PRO-AS7

Issue 004 - March 2022

CAME 
ENTROTEC

[CAME.COM/ENTROTEC](https://www.came.com/entrotec)



Legal and Copyright Notice

Entrotec regularly develop and enhance product lines, these changes will be included in the latest documentation. Whilst every effort has been made to ensure the accuracy of the information supplied herein, Entrotec is not responsible for any errors or omissions. Many of the images shown are for illustration purpose only. The actual product may vary due to product enhancement or custom configurations. The materials contained in this document are protected and may be subject to intellectual property rights.

Copyright 2021 Entrotec Limited. All rights reserved.

Installation Specification

It is the responsibility of the installer to follow Entrotec's installation and cable specification as well as ALL relevant wiring regulations. Failure to comply with Entrotec's installation and cable specification may result in erratic operation of equipment and could invalidate any warranty.

Installations must comply with the following applicable standards:

- **BS 7671:** Requirements for electrical installations. IET Wiring Regulations 18th Edition.
- **The Electricity at Work Regulations 1989**
- **ANSI/TIA-568.0-D:** Generic Telecommunications Cabling for Customer Premises.
- **ANSI/TIA-568.1-D:** Commercial Building Telecommunications Cabling Standard.

IET Wiring Regulations 18th Edition: Regulation 444 (MEASURES AGAINST ELECTROMAGNETIC DISTURBANCES) imposes requirements for segregation of circuits.

IET Wiring Regulations 18th Edition: Regulation 528 (PROXIMITY TO WIRING SYSTEMS TO OTHER SERVICES) imposes requirements for segregation of door entry / access control circuits (Band I), 230VAC mains circuits (Band II) and other higher voltage circuits.

IET Wiring Regulations 18th Edition: Regulations 541 and 542 impose requirements for earthing and bonding conductors. Ensure ALL metalwork is bonded to the buildings earth, this includes call panels, exit switches, cabinets and metal conduit. Ring terminals and earth points are provided on call panels and cabinets to terminate earth cables, ensure these connections are made.

WARNING - ISOLATION OF ELECTRICAL EQUIPMENT

In compliance with **The Electricity at Work Regulations 1989**, electrical equipment should be made dead to prevent danger while work is carried out on or near that equipment. No person shall be engaged in any work activity on or so near any live conductor.

Warranty and Support

Entrotec systems are renowned for their reliability and have a 2-year warranty on all Entrotec manufactured products as standard. This warranty does not cover water damage, vandalism, mains electrical faults, lightning strikes, damage caused by miswiring or cable faults.

Entrotec offer complimentary training courses and telephone support:

01506 886 235 - 8:30am to 5pm Mon-Thurs and 8:30am to 4pm Friday.

technicalsupport@entrotec.co.uk

Contents

1	Cable Specification	4
1.1	Typical Configuration	4
2	Overview.....	5
2.1	Call Panel.....	5
3	Connections	6
4	Factory Default Settings.....	7
5	Assign an IP address	7
6	Initialise	8
6.1	Connect to Web Service and Initialise Device	8
7	Login to Call Panel	10
8	Provision	11
8.1	Provisioning Systems without an Entrotec Connect Server.....	11
8.2	Provisioning Systems with an Entrotec Connect Server	13
8.3	Provisioning Systems with an Entrotec Connect Server Installed Retrospectively.....	14
9	Configure	15
9.1	Block Name	15
9.2	Video and Audio Settings.....	15
9.3	Lock Release Time.....	16
9.4	Coded Access	16
10	Apartment Station Configuration	17
10.1	Required Info	17
10.2	Factory Default Settings.....	17
10.3	Initialise.....	17
10.4	Provision	19
10.5	Configure.....	20
11	Device Registration.....	21
11.1	Required Info	21
11.2	Register Devices	21
11.3	Check Status.....	24

1 Cable Specification

The cabling system is based on Unshielded Twisted Pair **Category 5e** (Cat5e) or **Category 6** (Cat6). The cable must be **annealed pure copper**, meeting or exceeding the requirements defined in the standard ANSI/TIA 568 C.2.

Failure to comply with this cable specification may result in erratic operation of equipment.

The specification below shows the minimum cable requirements, allow for extra cabling if redundancy is required.

	Connection	Cable
A	Door controller with PSU to each call panel:	2x Cat5e or Cat6.
B	Lock Relay to locks:	2x 1.5mm ² multi-stranded flex or singles (route through any exit/fire switch or break glass for fail safe operation).
C	Lock Relay to exit switch:	1 Pair UTP (2 cores), Cat5e or Cat6.
D	Lock Relay to fire switch:	1 Pair UTP (2 cores), Cat5e or Cat6.

1.1 Typical Configuration




FIGURE 1-1

NOTE

Refer to the PRO-DC (Door Controller) Installation Guide for Lock and Exit Switch connections.

2 Overview

2.1 Call Panel

2.1.1 Front View




FIGURE 2-1

A	Security Fixings, M4, Tool Supplied
B	Microphone
C	Panel Camera
D	Display
E	Speaker
F	Keypad
G	RFID Proximity Reader

2.1.2 Back View




FIGURE 2-2

A	DO NOT USE
B	RS485 to Door Controller
C	Tamper Switch
D	Relay Output
E	Ethernet to Door Controller
F	Alarm Inputs
G	12VDC from Door Controller PSU

3 Connections




FIGURE 3-1

	Connection	Cable Type	Detail
A	RS485 to Door Controller		1 Pair UTP - RS485A+RS485B (1+2)
B	12VDC from Door Controller PSU - (DC connector supplied)	1x Cat5e or Cat6	1 Pair UTP - 12v (White) 2 Pair UTP - 0v (Black)
C	Ethernet to Door Controller	1x Cat5e or Cat6	RJ45 - T568B




FIGURE 3-2

4 Factory Default Settings

Setting	Default
IP Address	192.168.1.110
Subnet	255.255.0.0
Gateway	192.168.1.1
Device Admin Code	8, 8, 8, 8, 8, 8
Block No.	0
Door No.	8001

5 Assign an IP address

5.1.1 Configure Network Settings on Device

Before initialising a Call Panel, the default IP address should be configured to avoid conflicts with other devices with the same default settings. To apply the new network settings, enter the programming menu on the Call Panel by pressing the call button , then the Device Admin Code (default = 888888), then the call button .



FIGURE 5-1

- i. The first option in the menu 'IP Config' is selected, press the call button .




FIGURE 5-2

Initialise

- ii. Navigate the cursor to the different network segments using **2** (up), **8** (down), **4** (left) and **6** (right). The selected segment will blink.




FIGURE 5-3

- i. Press to adjust a segment and enter a new number using the keypad.
- ii. Press to save that segment.
- iii. Repeat steps 1-3 for each segment required and press **X** to exit the menu.

NOTE

The device will reboot if network settings are updated. This might take up to 2 minutes.

6 Initialise

NOTE

Settings differ between systems **WITH** and **WITHOUT** an Entrotec Connect Server. For systems without an Entrotec Connect Sever, one Call Panel on the system is assigned as the SIP server.

6.1 Connect to Web Service and Initialise Device

- i. Connect a laptop or PC to the same network as the Call Panel.
- ii. Assign your PC or laptop an IPv4 address from the same range used by the door entry system.
- iii. Use a web browser and enter the IP address of the Call Panel in to the address bar.




FIGURE 6-1

- iv. Enter a new admin password for the device and press **Next**.

⚠ WARNING

It is important to choose a **secure password** and manage it correctly. If a password is forgotten, the device may have to be restored to default settings. This may result in data loss.

- v. Enter a recovery email address (optional) and press **Next**.




FIGURE 6-2

7 Login to Call Panel

- i. Connect a laptop or PC to the same network as the Call Panel.
- ii. Assign your PC or laptop an IPv4 address from the same range used by the door entry system.
- iii. Use a web browser and enter the IP address of the Call Panel in to the address bar.
- iv. Login to the call panel using the following credentials:
 - Username: **admin**
 - Password: ***password setup during initialisation*** (Section 6.1)




FIGURE 7-1

8 Provision

NOTE ON ENTROTEC CONNECT SERVER

For systems where a PRO-ECS is fitted, or will be fitted later, use section 8.2.
For systems where no PRO-ECS will be fitted, use section 8.1.

8.1 Provisioning Systems without an Entrotec Connect Server

For systems without an Entronet Connect Sever, one Call Panel on the system is assigned as the SIP server. Sub Call Panels and Apartment Stations register to this Main Call Panel.

8.1.1 Configure SIP Server Settings for Sub Call Panels

NOTE

This section is for Sub Call Panels only. For Main Call Panel Setup, continue to section 9.

- i. Log in to the Sub Call Panel.
- ii. Navigate to **Network Settings**.




FIGURE 8-1

iv. Select SIP Server.




FIGURE 8-2

- v. Uncheck **Enable**, this disables the internal device SIP Server which is on as default.
- vi. For **Sever Type** select **VTO**.
- vii. Enter the Main Call Panel **IP Address**, **Port 5060**.
- viii. Press **Save**.

i NOTE

The device will reboot if the SIP Server is enabled or disabled. This might take up to 2 minutes.

8.1.2 Configure SIP ID

- i. Login to the Call Panel as described in section 7.
- ii. Navigate to **Local Settings** > **Basic**.
- iii. Set the **Block Name** - the text displayed on the first line when the panel is in its idle state.
- iv. Set the **Door No.** - each Call Panel on a block should have a unique number.
- v. Press **Confirm**.




FIGURE 8-3

8.2 Provisioning Systems with an Entrotec Connect Server

8.2.1 Configure SIP Server Settings

- i. Login to the Call Panel as described in section 7.
- ii. Navigate to **Network Settings > SIP Server**.




FIGURE 8-4

- iii. Uncheck **Enable**, this disables the internal device SIP Server which is on as default.
- iv. For **Server Type** select **Express\DSS**.
- v. Enter the Entrotec Connect Server **IP Address**, **Port 5080**.
- vi. Optional - enter the **Domain VDP**, **SIP Server Username** and **SIP Server Password**.
- vii. Press **Save**.

i NOTE

The device will reboot if the internal device SIP Server is enabled or disabled.

8.2.2 Configure the Alternate SIP Server

After applying the **SIP server** settings in Section 8.2.1, you can configure an alternate SIP Server. The **Alternate SIP** server will take over from the original in case of any down time. The panel configured to be the **Alternate SIP Server** is typically the main door panel in the system.




FIGURE 8-5

This can be configured following these steps:

- i. Set the **Alternate IP Addr.** to the main door panel IP address.
- ii. Insert the login details for the main door panel in the **Alternate Username** and the **Alternate Password**. These are the login details setup during initialisation (Section 6).
- iii. Check the **Alternate Server** to enable it.
- iv. Click **Save** to save the configuration.

8.2.3 Configure SIP ID

- i. Login to the Call Panel as described in section 7.
- ii. Navigate to Local **Settings** > **Basic**.
- iii. Set the **Block Name** - the text displayed on the first line when the panel is in its idle state.
- iv. Set the **Door No.** - each Call Panel on a block should have a unique number.
- v. Press **Confirm**.




FIGURE 8-6

8.3 Provisioning Systems with an Entrotec Connect Server Installed Retrospectively

When planning to install the ECS at a later stage, the door entry system can be configured so that the main door panel will work temporarily as the SIP server. Once the server is installed, it will automatically take over from the main door panel and start running the door entry system. For configuring e apartment stations for this system setup please go to section 10.4.1, step ii.b.

8.3.1 Configure SIP Server Settings

Follow the same steps as per section 8.2.1.

8.3.2 Configure the Alternate SIP Server

Follow the same steps as per section 8.2.2.

9 Configure

9.1 Block Name

- Login to the Call Panel as described in section 7.
- Navigate to **Local Settings > Basic**.
- Set the **Block Name** - the text displayed on the first line when the panel is in idle state.
- Press Confirm.




FIGURE 9-1

9.2 Video and Audio Settings

- Login to the Call Panel as described in section 7.
- Navigate to **Local Settings > Video & Audio**.
- These settings are application specific dependant on the location of the Call Panel.




FIGURE 9-2

NOTE

The maximum resolution is 720P. The PRO-AS7 Apartment Station display resolution is 480x800, therefore it may be most efficient to use the WVGA Video Format.

9.3 Lock Release Time

- i. Login to the Call Panel as described in section 7.
- ii. Navigate to **Local Settings > Access Control > Local**.
- iii. Set the **Unlock Retry Interval** and **Unlock Time**, for the desired lock release time.
- iv. Press Save - these settings update the onboard relay parameters.




FIGURE 9-3

- v. Navigate to **Local Settings > Access Control > RS485**.
- vi. Set the **Unlock Response Interval** and **Unlock Time**, for the desired lock release time.
- vii. Press **Save** - these settings update the parameters for the remote lock relay in the connected Door Controller.




FIGURE 9-4

9.4 Coded Access

- i. Login to the Call Panel as described in section 7.
- ii. Navigate to **Local Settings > Access Control > Local**.
- iii. Enter a 6-8 digit access code in the **Public Unlock Password** box.
- iv. Confirm the code in the box below and check 'Enable'.
- v. Press Save




FIGURE 9-5

10 Apartment Station Configuration

10.1 Required Info

To configure an Apartment Station, you will need to determine the IP address and SIP details.

10.2 Factory Default Settings

Setting	Default
IP Address	192.168.1.109
Subnet	255.255.0.0
Gateway	192.168.1.1
Device User Passcode	1, 2, 3, 4, 5, 6
Flat No.	9901

10.3 Initialise

10.3.1 Set Admin Password Settings on Device

- i. When the device is first powered, it will request an initial Device Admin Password and recovery email address.




FIGURE 10-1

- ii. Enter the **Password** which must be a 6-digit number.

WARNING

It is important to choose a **secure password** and manage it correctly.

- iii. Enter the recovery **Email**, this can be set to **support@entrotec.co.uk**




FIGURE 10-2

- iv. Press **OK** to save.

10.3.2 Configure Network Settings

- i. From the home screen, press and hold **Settings** for 5 seconds.




FIGURE 10-3

- ii. When the **Password Verification** screen appears, enter the device admin password setup in during initialisation.
- iii. Press **OK**.




FIGURE 10-4

- iv. The admin menu will open in the **Network** tab. Set the **IP Address**, **Subnet Mask** and **Gateway** address by pressing on the segment you wish to change.
- v. Press **OK** to save.




FIGURE 10-5

10.4 Provision

10.4.1 Configure Flat Number and SIP Server Settings

- i. Navigate to the **User Config** tab.
- ii. Enter the **Flat No.**
 - a. Systems **WITHOUT** an Entrotec Connect Server, enter the desired **Flat No.** e.g. 23
 - b. Systems **WITH** an Entrotec Connect Server, enter the desired **Flat No. followed by #0** e.g. 23#0.

i NOTE

The #0 parameter identifies the apartment station as the Master within the same property. Any additional Slaves must be identified (e.g. 23#1 for slave 1, 23#2 for slave 2).




FIGURE 10-6

- iii. Press **OK** to save.
- iv. Navigate to the **SIP Server** tab.




FIGURE 10-7

- v. Enter the following SIP Details:
 - a. Systems **WITHOUT** EC Server; **Server IP** Main Call Panel IP, **Network Port** 5060.
 - b. Systems **WITH** an EC Server; **Server IP** Entrotec Connect Server IP, **Network Port** 5080.

i NOTE

DO NOT adjust Register Pwd

- vi. Optional - enter the **Domain** VDP, SIP Server **User Name** and **Login Pwd**.
- vii. Press **OK** to save.

10.4.2 Configure Doors

- i. Navigate to the **Door Config** tab.
- ii. Enter the details for the Main Call Panel and any Sub Call Panels.




FIGURE 10-8

i NOTE

Password is the Call Panel Device Admin Password.

- iii. If the **Enable** switch is **OFF** set it to **ON** after making any changes.
- iv. If the **Enable** switch is **ON** set it to **OFF**, then **ON** again. This forces a synchronisation of settings between the apartment station and the door panel, this takes a few seconds to complete.

10.5 Configure

10.5.1 Accessing Device Settings

- i. From the home screen, short press **Settings**.




FIGURE 10-9

- v. When the **Password Verification** screen appears, enter the device user passcode.
- vi. Press **OK**.




FIGURE 10-10

NOTE

The User Password can be changed or disabled to allow easier access to the user menu.

11 Device Registration

NOTE

This section is only for systems **WITHOUT** an Entrotec Connect Server where the function of the SIP Server is assigned to the main call panel.

11.1 Required Info

To register devices to the Main Call Panel (SIP Server), the following is required.

SIP ID of the Sub Call Panels (Door No.)

SIP ID Apartment Stations (Flat No.),

IP Address, Username, Password, Port Number, etc. of any separate IP Cameras.

11.2 Register Devices

11.2.1 Register Apartment Stations

- i. Login to the Main Call Panel as described in section 7.
- vii. Navigate to **System Settings > Flat No. Management**.
- viii. Press **Add**.




FIGURE 11-1

Device Registration

- ix. Enter the **Flat No.**
- x. Enter **Nick Name** if required, this is displayed at the Call Panel when scrolling the contacts.
- xi. Press **Save**.




FIGURE 11-2

Repeat steps viii-xi for additional Apartment Stations.

11.2.2 Register Sub Call Panels

- i. Login to the Main Call Panel as described in section 7.
- ii. Navigate to **System Settings > Door No. Management**.
- iii. Press **Add**.




FIGURE 11-3

- iv. In **Rec No.** Enter the **Door No.** set in section 8.1.1
- v. Enter the **Block Name**.
- vi. Press **Save**.




FIGURE 11-4

Repeat steps ii-vi for additional sub call panels.

11.2.3 Register IP Cameras

- i. Login to the Main Call Panel as described in section 0.
- vii. Navigate to **System Settings > Camera Settings**.
- viii. Choose the first unused entry and press **Modify**.




FIGURE 11-5

- ix. Enter a user-friendly **Camera Name**.
- x. Enter the **IP Address** for the camera and device specific settings as required.
- xi. Press **Save**.





FIGURE 11-6

Repeat steps viii-xi for additional cameras.



11.3 Check Status

- i. Login to the Main SIP Server Call Panel as described in section 7.
- xii. Navigate to **System Settings > Status**.




FIGURE 11-7

All SIP devices registered to the Main Call Panel are displayed. If a device has gone offline, it will display the last **Off Time**.



CAME ENTROTEC

CAME ENTROTEC

5 Ashwood Court
Oakbank
Livingston
EH53 0TL

Tel: 01506 886230

Support: 01506 886235



© PRODPCGUIDE0322 - 2022 - EN
YOU MAY NOT EVEN PARTIALLY REPRODUCE THIS DOCUMENT
THE DATA AND INFORMATION SHOWN IN THIS CATALOGUE ARE SUBJECT TO CHANGE WITHOUT OBLIGATION TO GIVE PRIOR NOTICE BY CAME S.P.A, E&OE



CAME S.p.A.
Came cancelli automatici S.p.A.
is certified for Quality and Environment
UNI EN ISO 9001
UNI EN ISO 14001
BS OHSAS 18001

[CAME.COM/ENTROTEC](https://www.came.com/entrotec)